

18A Dispenser



The 18A has been specifically designed to work in conjunction the 3A Blown Fibre Blowing Unit.

The 18A dispenser secures the 3A blowing head during the installation and with the hoses connected delivers air from the compressor through a pressure regulator, isolating and vent valve to the blowing head. The pigtail mounted on the platform section guides the fibre from the pan into the blowing head.

The dispenser incorporates a pressure regulator and gauge, which is set at 10 bar for 5/3.5mm duct and includes a distance scale for setting the correct pressure of 8/6mm duct.

If you are installing blown fibre unit in a tight congested space, such as when centre blowing, the blowing head platform can be disconnected from the regulator and gauge section using 2 thumbs screws in the base. Air is then connected between the 2 parts using the extension hose provided.



3A Blowing Head Mounted onto 18A Dispenser

3A Blowing Head Mounted onto 18A Platform and disconnected from Regulator / Gauge Section

